

## Leadstar PCC Techwell 9mm Glock Mag Installation Instructions

First a couple of practical things, 1. We recommend that Purple Loctite 222 or Vibra-Tite VC-3 (at least Blue Loctite) is put onto the threads of all screws to make sure they never loosen, and 2. Make a mark of some kind exactly above the holes on the inserts to make it easier to line them up with the Techwell body screw holes.

Now the set-up concepts:

Photo 1 shows the Techwell body, inserts, screws and provided hex. Photo 2 shows the beveled edges of the inserts which face INWARDS.

Photo 1



Photo 2



Photo 3 shows the insertion position of the left side insert and Photo 4 shows the insert position on the right (mag release) side.

Photo 3



Photo 4



Finally, the simple installation process:

**Photo 5 - Put the LEFT insert into position and then slide the Techwell body up onto it matching the holes, then carefully thread in the screws, DO NOT over tighten them (meaning don't strip the Delrin), their primary job is to hold everything in position, so just thread in until it feels like the heads have met the Techwell body and came to rest.**

**Next and final, Photo 6 – Slide the right side insert into place carefully matching up the holes, and perform the same screw insertions. Et Voila, you are set to go, and go great!!**

**Photo 5**



**Photo 6**



**Finished installation photos:**



**Any questions or issues don't hesitate to get with us, we're there for you. Thanks for your business and great shooting!!!**