

RUGER PCC Techwell for 9mm Glock Mag Installation Instructions

U.S. Patents Number 10,101,105, and D841,758

First, we recommend that Purple Loctite 222 or Vibra-Tite VC-3 is put onto the threads of the screws to make sure they never loosen.

Now referring to Photo 1, note the Techwell body angle; the front (below the mag release) is somewhat shallower than the rear. Now, carefully yet firmly, push up the Techwell until uniform contact is made with the front and rear “bumpers”. Next, push in and down the “L” insert on the left side of the Techwell as indicated in Photo 1, and align the screw holes. Gently use the hex wrench to make sure the Techwell body screw holes are perfectly positioned with the insert holes (as in Photo 2), then install the two screws, and tighten until snug.



Photo 3 is shown to indicate that there is no letter “R” on the right side insert, just follow the same instructions as above to align the holes and install the screws ... Et Voila, Photo 4 shows the completed installation, and you are set to perform the fastest and smoothest reload that can be done on any carbine, go impress the rest!

