

Primary Weapons System PCC Techwell Glock 9mm Mag Installation Instructions

Before you begin, we recommend that Purple Loctite 222 or Vibra-Tite VC-3 is put onto the threads of the screws to make sure they don't loosen. Now, though the first installation photo immediately below is not of the Primary Weapons System lower, the installation method is exactly the same ...



Et voila, good to go!!

Again, as instructed above, don't over-tighten, there is no need, you'll see ;) Any questions or issues don't hesitate to get with us, we're there for you. Thanks for your business and great shooting!!!

CRITICAL NOTE PLEASE READ - If your lower has an additional coating on it (meaning over the hard coat anodization they all begin with), you may need to sand down the inside contact areas slightly. If you need some additional installation information BEFORE INSTALLATION. Please sign on to this specific link on our website: <https://techwellusa.com/pcc-coated>